

## Are you starting up?

(First user of the day on Weekends, Holidays and outside weekly working hours)

Turn on the Computer and the Cytometer.  
Login on Windows and Login on SpectroFlo.  
Follow the **startup cleaning procedure**:



**WATER+AZIDE**  
RUN + HIGH  
wait 30 min

Run the Quality Control with SpectroFlo beads.

You are ready to run your samples!

**Thank you!**